

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

www.empero.nt-rt.ru | | eov@nt-rt.ru

Технические характеристики на тестомесы на колесиках, тестомесильные машины спиральные компании **EMPERO GROUP**

Dough Kneading Machines (with Wheels)



- Emergency stop.
- Stainless steel bowl and dough mixer arm.
- Automatic stopper switch feature when the cover is opened.
- Silent and without vibration working.

HY.11.K / HY.12.K

- Motor Power: 0.37 kW 1400 rpm / 220V - 380V

HY.01.K / HY.02.K

- Motor Power: 0.55 kW 1400 rpm / 220V - 380V

HY.03.K / HY.04.K

- Motor Power: 0.55 kW 1400 rpm / 220V - 380V

HY.05.K / HY.06.K

- Motor Power: 0.75 kW 1400 rpm / 220V - 380V

HY.07.K / HY.08.K

- Motor Power: 1.10 kW 1400 rpm / 220V - 380V

Code	Description	Dimensions mm			Weight kg	Net m3	Bowl Dimensions mm	Flour Capacity kg	Capacity lt
		a	b	c					
HY.11.K	Dough Kneading Machine 15 kg (220 V)	424x700x647			58	0.19	360x190	7	15
HY.12.K	Dough Kneading Machine 15 kg (380 V)	424x700x647			58	0.19	360x190	7	15

HY.01.K	Dough Kneading Machine 30 kg (220 V)	550x860x780	78	0.25	430x225	12	30
HY.02.K	Dough Kneading Machine 30 kg (380 V)	550x860x780	78	0.25	430x225	12	30
HY.03.K	Dough Kneading Machine 40 kg (220 V)	610x910x780	92	0.40	500x270	20	40
HY.04.K	Dough Kneading Machine 40 kg (380 V)	610x910x780	92	0.40	500x270	20	40
HY.05.K	Dough Kneading Machine 50 kg (220 V)	646x955x794	106	0.49	600x290	30	50
HY.06.K	Dough Kneading Machine 50 kg (380 V)	646x955x794	106	0.49	600x290	30	50
HY.07.K	Dough Kneading Machine 75 kg (220 V)	815x1130x882	140	0.78	750x350	50	75
HY.08.K	Dough Kneading Machine 75 kg (380 V)	815x1130x882	140	0.78	750x350	50	75

Double Speed Spiral Dough Mixers (with Wheel)



- Two speed dough mixer arm.
- Control panel with adjustable timer .
- Emergency stop.
- Stainless steel bowl and dough mixer arm.
- Automatic stopper switch feature when the cover is opened.
- Ideal machine for kneading all kinds of dough.

SH.01

- Motor power: 1.0 - 1.7 kW - 750/1500 rpm 380V
- Bowl size: 400x260 mm

SH.02

- Motor power: 1.5 - 2.5 kW - 750/1500 rpm 380V
- Bowl size: 500x300 mm

SH.03

- Motor power: 1.5 - 2.5 kW - 750/1500 rpm 380V
- Bowl size: 600x315 mm

Code	Description	Dimensions mm			Weight kg	Net m3	Flour Capacity kg	Capacity lt
		a	b	c				
SH.01	Spiral Dough Mixer 30 kg	432x792x987			174	0.34	12	30
SH.02	Spiral Dough Mixer 50 kg	544x912x1065			208	0.53	20	50
SH.03	Spiral Dough Mixer 60 kg	637x1040x1105			240	0.73	35	60

Mono Speed Spiral Dough Mixer (with Wheels)



- Control Panel with adjustable timer.
- Emergency stop.
- Stainless steel bowl and dough mixer arm.
- Automatic stopper switch feature when the cover is opened.

SH.04

- Motor power: 1.1 kW 900 rpm 380V
- Bowl size: 360x210 mm

SH.05

- Motor power: 1.5 kW 900 rpm 380V
- Bowl size: 400x260 mm

SH.06

- Motor power: 1.5 kW 900 rpm 380V
- Bowl size: 500x300 mm

Code	Description	Dimensions mm			Weight kg	Net m3	Flour Capacity kg	Capacity lt
		a	b	c				
SH.04	Spiral Dough Mixer 15 kg	433x756x933			160	0.31	7	15
SH.05	Spiral Dough Mixer 30 kg	433x790x990			174	0.34	12	30
SH.06	Spiral Dough Mixer 50 kg	544x911x1065			202	0.53	20	50

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

www.empero.nt-rt.ru | | eov@nt-rt.ru